

Front Strut Top Mount Bush-44CF

Designed To Lower Suspension by 10mm



C



B



A



D

Fitting Instructions

1. Remove the Front Strut from the Vehicle.
2. Remove the original Top Mount by using a spring compressor to release the tension.
3. Check the condition of the bearings(D), Metal cups(C) and Nuts these will need to be reused, replace if required.
4. Fit the New Top Mount Bush(A) to the strut, in the same configuration as when removing the old Bush.
5. Fit the metal cup(C) into Top Washer Bush(B)
6. Refit the strut and bolt The metal Cup and Washer to the Top.
7. Finally Tighten the Nuts to the manufacturers recommended Torque settings.